function	potential failure (e.g. its state)	effect of failure (e.g. its consequence)	cause	preventive measures	IEC 61508 techniques
read current	Stuck-at	wrong current (static)	ADC/hardware	ADC/hardware self test	fault detection